







Germany

### MM12031

NO.	DESCRIPTION
1	KNOB
2	TOP-COVER
3	PLATE
4	KEY-HOLD
5	LCD COVER
6	LCD
7	KEY
8	PCB
9	BATTERY WALL COVER
10	FOIL BATTERY
11	BOTTOM COVER

RU6041402



Germany

Germany