



MS55206

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	BASE PAD	36	BEARING 6201Z	71	ROTOR
2	NUT	37	BEARING HOLDER	72	BEARING 608Z
3	PLAIN WASHER	38	OUTPUT SHAFT	73	STATOR
4	BASE	39	BIG GEAR	74	BEARING COVER
5	STEEL BALL	40	NEEDLE BEARING HK0709	75	MOTOR HOUSING
6	SPRING	41	LOCK BAR	76	LABEL
7	LOCKING COVER	42	SPRING	77	CIRCLE INDUCTOR
8	TAPPING SCREW	43	TAPPING SCREW	78	BRUSH HOLDER PAD
9	ROTATION PLATE	44	CIRCLIP	79	REAR COVER
10	SCREW	45	BAR CONNECTION	80	LOCK SLEEVE
11	HEX NUT	46	BOLT	81	WASHER
12	LOCATING PAD	47	CORD CLAMP	82	BOLT
13	NUT	48	PAD	83	O-RING
14	SPRING WASHER	49	SLEEVE PAD	84	LOCK PIN
15	HEX SCREW	50	SPRING	85	NUT
16	SCREW	51	TAPPING SCREW	86	LOCK CAP
17	FENCE	52	SCREW	87	CORD SLEEVE
18	RIVET	53	KEY	88	CORD & PLUG
19	MOVABLE GUARD	54	CIRCLIP	89	HEX NUT
20	WASHER RING	55	LOCK OFF BUTTON	90	SCREW
21	GUARD PRESSURE BOARD	56	SUNK SCREW	91	HEX NUT
22	INNER FLANGE	57	SCREW	92	BOLT
23	SAW BLADE	58	HEX NUT	93	BRACKET
24	OUTER FLANGE	59	TAPPING SCREW	94	HEX NUT
25	WASHER	60	FRAME	95	RIGHT BAFFLE
26	HEX SCREW	61	TAPPING SCREW	96	LEFT BAFFLE
27	OUTER COVER SHELL	62	RIGHT HANDLE	97	SUNK SCREW
28	NAME PLATE	63	SWITCH	98	SCREW
29	SUNK SCREW	64	NUT	99	WASHER
30	GEMEL	65	TAPPING SCREW	100	PIN
31	SUNK SCREW	66	LEFT HANDLE	101	BRACKET
32	JOINT BAR	67	"D" TYPE INDUCTOR	102	INDICATOR
33	NUT	68	CAPACITOR	103	LOCK HANDLE
34	PULLEY	69	WINDBAFFLE		
35	SCREW	70	BEARING 6000Z		