



MS55305B

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	44	FAN BAFFLE	89	MOVING GUARD COVER	133	SOCKET HEAD SCREW	176	SUPPORT ARM
2	SPRING WASHER	45	STATOR	90	SHOULDER SCREW	134	BEVEL POINTER	177	KNOB(SHORT)
3	WASHER	46	ARMATURE	91	LINKAGE(A)	135	SCREW	178	WORKPIECE KNOB
4	BELT COVER	47	BEARING 6000	92	RIVET	136	BEVEL SCALE	179	SUPPORT POLE
5	SOCKET HEAD SCREW	49	RUBBER BOOT	93	SOCKET HEAD SCREW	137	STRAIGHT CUT SETTING PIN	180	SCREW
6	WASHER	50	MOTOR HOUSING	94	LINKAGE(B)	138	STUD	181	KNOB(SHORT)
7	BELT	51	SCREW	95	TORSION SPRING	139	STUD	182	KNOB(LONG)
8	GEAR LOCK PIN	52	BRUSH HOLD	96	SPRING BUSHING	140	LOCKNUT	183	RIGHT ATTACH FENCE
9	GEAR LOCK PIN SPRING	53	BRUSH SPRING	97	TRENCH DEPTH BRACKET	141	WASHER	184	LOCK WASHER
10	E CLIP	54	BRUSH	98	SPRING PIECE	142	SOCKET HEAD SCREW	185	HEAD SUNK SCREW
11	BELT PULLEY(BIG)	55	SCREW	99	WAVE WSHR	143	TURNTABLE	186	ORIENTATION BOARD(SMALL)
12	BELT PULLEY(SMALL)	56	MOTOR COVER	100	SCREW	144	SCREW	187	SPRING WASHER
13	SCREW	58	BLADE BOLT	101	PIVOT SHAFT	145	CUTTING INSERT	188	SOCKET HEAD SCREW
14	HEX GRUB SCREW	59	BLADE FLANGE OUTER	102	STEEL WIRE BAFFLE RING	146	SPRING	189	SPRING
15	EXHAUST PORT	60	BLADE	103	BRACKET	147	SOCKET HEAD SCREW	190	SPRING WASHER
16	WASHER	61	BLADE FLANGE INNER	104	LINEAR BEARING	148	DETENT POLE	191	WAVE WASHER
17	SPRING WASHER	62	SCREW	105	BEARING COVER	149	MITER POINTER	192	NUT
18	SCREW	63	GEAR CASE COVER	106	SCREW	150	SCREW	193	CAPACITOR
19	SCREW	64	BEARING 608	107	LINEAR BEARING	151	TURNTABLE BOLT	194	SCREW
20	LASER SWITCH	65	SHAFT GEAR	108	SPRING LOOP	152	TURNTABLE BOLT COVER	195	WASHER
21	LASER SWITCH CAP	66	FLAT KEY	109	KNOB(LONG)	153	SCREW	196	SHIELD LOCK PIECE
22	CABLE PLUG	67	BEARING 6001	110	SOCKET HEAD SCREW	154	KNOB(LONG)	197	SHIELD LOCK SHEET
23	CORD PROTECTOR	68	KEY	111	LOCK PIN	155	SAFETY FOOT	198	SPRING
24	COLD CLAMP	69	SPINDLE	112	ROLLED PIN	156	SCREW	199	WASHER
25	SCREW	70	C CLIP	113	LOCK PIN SPRING	157	SPRING	200	LOCKNUT
26	COLD CLAMP	71	BEARING 6203	114	LOCK PIN CAP	158	KNOB	201	WASHER
27	SCREW	72	GEAR	115	BEARING COVER	159	LOCK BOOT	202	SPRING WASHER
28	TRANSFORMER	73	BEARING 6000	116	LASER FIXED PLATE	160	LOCK BOLT	203	SCREW
29	TRIGGER	74	FIXED GUARD	117	SCREW	161	SUPPORT BAR	204	LOCK HANDLE CAP
30	SCREW	75	DUST PIPE RUN	118	DUAL LASER CARRIER	162	LOCK HANDLE	205	SCREW
31	CARRY HANDLE	76	SUNK SCREW	119	SCREW	163	SCREW	206	LOCK HANDLE
32	SCREW	77	NUT	120	LASER	164	LOCK HANDLE CAP	207	FIXTURE
33	UPPER HANDLE	78	PLATE GUARDING(BIG)	121	SCREW	165	BASE	208	LOCKED NUT
34	BINDING POST	79	PLATE GUARDING(SMALL)	122	LASER CASE	166	RUBBER FOOT	209	PIN
35	SWITCH	80	MOVING GUARD PLATE	124	HEX GRUB SCREW	167	MITRE SCALE	210	ROLED PIN
36	LOWER HANDLE	81	BIG WASHER	125	ARM	168	SHOULDER SCREW	211	LOCK BOLT
37	DEPTH OF CUT ADJUST KNOB	82	SCREW	126	RUBBER RING	169	SCREW	212	PRESSURE PLATE
38	SOCKET HEAD SCREW	83	SPRING	127	SLIDE	170	SUPPORT BAR	213	WASHER
39	NUT	84	CAST CENTRE	128	BEVEL LOCK HANDLE	171	FENCE	214	SCREW
40	KNURLED THIN NUT	85	SCREW	129	WASHER	172	SOCKET HEAD SCREW		
41	MOTOR SUPPORT	86	RIVET	130	LOCKNUT	173	LEFT ATTACH FENCE		
42	SCREW	87	SCREW	131	WASHER	174	SCREW		
43	BEARING 6201	88	MOVING GUARD	132	NUT	175	CLAMP		