



## OS8120R

NO.	DESCRIPTION	NO.	DESCRIPTION
1	LABEL	24	BEARING 629
2	SCREW ST4.2×19	25	FAN
3	SCREW M4×10	26	BEARING BASE
4	COPING	27	BEARING 6002
5	SQUARE NUT M4	28	WASHER
6	HANDLE BUFF	29	SPRING WASHER
8	SCREW	30	SCREW M5×18
9	RIGHT AUXILIARY HANDLE	31	ALUMINIUM BASE
10	LEFT AUXILIARY HANDLE	32	DUST BOX
11	KNOB	33	DUST BOX COVER
12-2	CARBON BRUSH HOLDER	34	DUST GUIDE BOARD
12-3	CARBON BRUSH	35	SCREW M4×12
13	SWITCH	37	150 BASE
14	CAPACITOR	38	SCREW M5×12
15	SCREW ST4.2×14	39	150 PAPER
16	CORD ANCHORAGE	40	125 BASE
17	CORD GUARD	41	125 PAPER
18	POWER CORD&PLUG	42	INDUCTOR
20	LABEL	43	WASHER
21	STATOR ASSEMBLY	888	HOUSING ASSEMBLE
22	BEARING 608		
23	ROTOR ASSEMBLY		

ST20111208-01

Sturmm!  
POWER • GAS • HAND • TOOLS