



ENGINE FOR PG8722E PG8728E

No.	DESCRIPTION	No.	DESCRIPTION	No.	DESCRIPTION
1	CLIP	41	OIL LEVEL SWITCH ASSY	81	SPARK PLUG
2	TUBE	42	GOVERNOR WEIGHT HOLDER	82	CYLINDER HEAD COMP
3	FUEL TANK JOINT	43	GOVERNOR WEIGHT PIN	83	CYLINDER HEAD GASKET
4	FUEL FILLER CAP COMP	44	GOVERNOR SHAFT	84	INTAKE VALVE
5	OIL FILTER	45	GOVERNOR HOLDER CLIP	85	EXHAUST VALVE
6	FUEL TANK COMP	46	GOVERNOR WEIGHT	86	VALVE LIFTER
7	THROTTLE RETURN SPRING	47	GOVERNOR SHAFT WASHER	87	CAMSHAFT ASSEMBLY
8	GOVERNOR SPRING	48	GOVERNOR COVER	88	DOWEL PIN 8*14
9	GOVERNOR ARM	49	CRANKSHAFT COMP	89	PIVOT ADJUSTING NUT
10	NUT M6	50	CASE OVER PACKING	90	ROCKER ARM PIVOT
11	LOCK PIN	51	OIL FILLER CAP ASSEMBLY	91	VALVE ROCKER ARM
12	GOVERNOR ARM SHAFT	52	OIL FILLER CAP PACKING	92	PIVOT BOLT
13	GOVERNOR ROD	53	CRANKCASE COVER	93	PUSH ROD GUIDE PLATE
14	FLANGE BOLT M6X12	54	FLANGE BOLT M8X32	94	PUSH ROD
15	GOVERNOR ARM BOLT	55	FLANGE BOLT M6X8	95	KEY
16	CONTROL ASSEMBLY	56	AIR CLEANER COVER NUT	96	SCREWSM5X8
17	GOVERNOR WASHER	57	AIR CLEANER CAP	97	MUFFLER PROTECTOR
18	RECOIL STARTER KNOB	58	AIR CLEANER CAP PACKING	98	MUFFLER COMP
19	RECOIL STARTER COMP	59	AIR CLEANER COVER	99	NUT M8
20	RECOIL STARTER SPRING	60	AIR CLEANER ELEMENT	100	MUFFLER PACKING
21	RECOIL STARTER ROPE	61	AIR CLEANER GRID	101	STUD BOLT
22	RECOIL STARTER REEL	62	AIR CLEANER ELBOW COMP	102	SHROUD COMP
23	RETURN SPRING	63	FLANGE BOLT M6X25	103	FIRST RING SET
24	STARTER RATCHET	64	IGNITOR		SECOND RING SET
25	RATCHET GUIDE	65	DOWEL PIN 10*16		RING COMP
26	SETTING SCREW	66	FLANGE BOLT 8*55	104	PISTON
27	SWITCH	67	CARBURETOR WASHER	105	PISTON PIN CLIP
28	FAN COVER COMP	68	CHOKE LEVEL COMP	106	PISTON PIN
29	NUT M14	69	CARBURETOR ASSEMBLY	107	CONNECTING ROD COMP
30	START HUB	70	CARBURETOR PACKING	108	OIL FILLER CAP
31	COOLING FAN	71	CARBURETOR INSULATOR	109	FAN COVER COMP
32	FLY WHEEL	72	INSULATOR PACKING	110	CONTROL ON-OFF
33	SIDE PLACE	73	STUD BOLT 6*113	111	FLY WHEEL
34	OIL SEAL	74	BREATHER TUBE	112	FLANGE BOLT M6*10
35	DIODE BASE COMP	75	HEAD OVER COMP	113	ELECTRIFG COIL
36	DIODE COMP	76	HEAD OVER PACKING	114	WIRE FLAT
37	DRAIN PLUG BOLT	77	VALVE ROTATOR	115	CONTROL ASSY
38	DRAIN BOLT WASHER	78	INTAKE VALVE SPRING RETAINER	116	RELAY
39	CRANKCASE	79	EXHAUST VALVE SPRING RETAINER	117	START MOTOR
40	RADIAL BALL BEARING 6205	80	VALVE SPRING		