

GENERATOR BLOCK


ENGINE BLOCK

CONTROL BOX BLOCK

COMBINATION SWITCH

	IG	E	BAT	ST	FS	G	A	B
OFF	○	○			○	○		
ON							○	○
ST			○	○				○

B	BLACK	Br	BROWN
Y	YELLOW	B/W	BLACK WHITE
L	BLUE	W/G	WHITE GREEN
G	GREEN	G/Y	GREEN YELLOW
R	RED	W/L	WHITE BLUE
W	WHITE	In	INDIGO



SPARKING PLUG

CHARGE COIL

BATTERY STARTER

ELECTRO-CONTROL CHOKE VALVE ASSY.

TRANSITION

OIL LEVEL SW