



PS9301

NO.	DESCRIPTION	NO.	DESCRIPTION
1	NORMAL WORK INDICATOR	20	POWER SWITCH
2	EXCESS VOLTAGE INDICATOR	21	DELAY TIME SELECTOR
3	LACK VOLTAGE INDICATOR	22	BOLT & NUT
4	DELAY TIME INDICATOR	23	EARTH SCREW
5	VOLT METER	24	SCREW
6	OUTPUT SOCKET(110V)	25	PCB
7	OUTPUT SOCKET(220V)	26	SCREW
8	SCREW	27	GEAR LOCATION SLEEVE
9	COVER	28	DC MOTOR
10	TRANSFORMER ASSEMBLY	29	DOUBLE GEAR II
11	MICRO SWITCH ASSEMBLY	30	DOUBLE GEAR III
12	CARBON BRUSH ASSEMBLY	31	DOUBLE GEAR I
13	BOTTOM BOARD	32	GEAR BOX BOTTOM
14	FRONT BOARD	33	BUSH
15	EARTH NUT	34	GEAR BOX COVER
16	CORD & PLUG	35	SPINDLE & GEAR
17	BOLT & NUT	36	TRANSFORMER STAND
18	FUSE	37	LIFT HANDLE
19	CORD CLAMP		

RU090722-1