



PS9302

NO.	DESCRIPTION	NO.	DESCRIPTION
1	COVER	34	BOLT
2	VOLT METER	35	SPRING WASHER
3	SCREW	36	PLAIN WASHER
4	AMPERE METER	37	MOTOR STAND
5	LIFT HANDLE	38	LOCATION PIN
6	DELAY TIME INDICATOR	39	BUSH
7	LACK VOLTAGE INDICATOR	40	DOUBLE GEAR II
8	EXCESS VOLTAGE INDICATOR	41	DOUBLE GEAR I
9	NORMAL WORK INDICATOR	42	DOUBLE GEAR III
10	CIRCUIT BREAKER	43	DC MOTOR PINION
11	INPUT AND OUTPUT TERMINAL	44	COPPER BUSH
12	SAFETY COVER	45	GEAR SPINDLE
13	SCREW	46	DC MOTOR
14	MICRO-SWITCH ASSEMBLE	47	GEAR IV
15	BOLT-NUT	48	GEAR BOX BOTTOM
16	TRANSFORMER ASSEMBLE	49	TRANSFORMER STAND
17	CARBON BRUSH HOLDER ASSEMBLE	50	GEAR LOCATION SLEEVE
18	RUBBER PAD	51	GEAR V
19	RUBBER PAD STAND	52	BIG GEAR
20	NUT	53	BOLT
21	SPRING WASHER	54	SPRING WASHER
22	PLAIN WASHER	55	PLAIN WASHER
23	WIRE TERMINAL	56	PCB ASSEMBLE
24	FRONT BOARD	57	BEAM
25	BREAKER FIXTURE	58	TAPPING SCREW
26	SCREW	59	SAFETY COVER CLAMP
27	BACK BOARD	60	SCREW
28	SCREW	61	BUSH
29	TAPPING SCREW	62	TAPPING SCREW
30	RUBBER FOOT	63	DELAY TIME SELECTOR
31	BOLT	64	CARBON BRUSH
32	SPRING WASHER	65	DRIVE SPINDLE
33	PLAIN WASHER	66	CABLE & PLUG