



PS9330

NO.	DESCRIPTION	NO.	DESCRIPTION
1	RUBBER SEAL	30	FAN
2	DELAY TIME SELECTOR	31	MICRO-SWITCH ASSEMBLY
3	CIRCUIT BREAKER	32	TRANSFORMER ASSEMBLY
4	VOLTAGE CHANGE-OVER SWITCH	33	CARBON BRUSH HOLDER ASSEMBLY
5	AMPERE METER	34	THERMOSTAT
6	VOLT METER	35	RUBBER PAD
7	AMPERE METER INDICATOR	36	TRANSFORMER BASE
8	CASTER ASSEMBLY	37	AC INSTALLATION PLATE
9	LOCK	38	INPUT & OUTPUT TERMINAL
10	FRAME	39	CURRENT TRANSFORMER
11	SCREW	40	AC CONTACTOR
12	BREAKER-FIXED PLATE	41	BUSH
13	DC MOTOR STAND	42	BIG GEAR
14	SCREW	43	DC MOTOR
15	PCB ASSEMBLY	44	GEAR BOX BOTTOM
16	SCREW	45	GEAR LOCK ASSEMBLY
17	SCREW & WASHER & SPRING WASHER	46	GEAR IV
18	TRANSFORMER-FIXED PLATE	47	CARBON BRUSH DRIVE AXIS
19	EARTHED SCREW	48	COPPER SLEEVE
20	BOLT & NUT	49	GEAR V
21	PLASTIC BUCKLE	50	GEAR SPINDLE
22	COMPENSATED TRANSFORMER ASSEMBLY	51	SMALL GEAR
23	INSULATION PAD	52	CARBON BRUSH
24	METAL PRESS RING	53	DOUBLE GEAR I
25	RUBBER RING & INSULATION PAPER	54	BUSH
26	COMPENSATED TRANSFORMER BASE	55	DOUBLE GEAR II
27	BOLT & NUT	56	GEAR AXIS
28	SCREW	57	DOUBLE GEAR III
29	COMPENSATED TRANSFORMER-FIXED PLATE	58	LOCKING PIN

RU090807-1