



RH2512M

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	FRONT CAP	40N	SECOND GEAR	77	ROTOR
2	RETAINER RING Ø28	41	RETAINER RING Ø15	78	BEARING 608
3	WASHER	42	PIN 4 X 14	79	BEARING SOCKET
4	SLIDER	43	CLUTCH	80	AIR BAFFLE
5	COLUMN PIN Ø8*19	44	BEARING AXK2542	81	TAPPING SCREW ST4.8 X 60
6	SPRING	45	WASHER	82	STATOR
7	CYLINDER CASE	46	DISHING SPRING	83	MOTOR HOUSING
8	PIN B4*20	47	BEARING 608	406	FLAT WASHER Ø5
9	OIL SEAL	48	DECORATION PLATE	407	SPRING WASHER Ø5
10	GUARD RING SLEEVE	49	SCREW M4 X 10	84	BOLT M5 X 50
11	O-RING	50	RETAINER RING Ø10	85	BRUSH HOLDER
12	SECOND STRIKER	401	WASHER	86	TAPPING SCREW ST4.2 X 10
13	O-RING	51	SIDE MODE SWITCH	87	CARBON BRUSH
14	STEEL BALL Ø7.14	52	LOCK BUTTON	408	WHORL SPRING
16	AXILE RETAINER RING 40	53	SPRING Ø6.1 X 46.2 X Ø0.8	88	BOTTOM COVER
17	BIG WASHER	54	SCREW M4 X 12	89	TAPPING SCREW ST4.2 X 12
18	SPRING SOCKET	55	INPECTION HOLE COVER	409	BOLT M5 X 20
19	BEARING 61808	403	BOLT M5 X 20	90	RIGHT HANDLE
20	STEEL BALL Ø9	404	SPRING WASHER Ø5	91	TAPPING SCREW ST4.2 X 16
21	CYLINDER	405	FLAT WASHER Ø5	92	CABLE CLAMP
22	LOCK-RELEASE SPRING	56	O-RING Ø36.5X1.8	93	CABLE SHEATH
23	BUSHING	60	CRANK CASE COVER	94	CABLE
24	PIN 3 X 18	61	DIRECTIONAL WASHER	95	CAPACITANCE
25	LOCK-RELEASE CLUTCH	62	OIL BEARING	96	INDUCTANCE
26	BIG BEVEL GEAR	63	STOPPER	97	SWITCH
27	AXILE STEEL-WIRE RETAINER 32	64	SEAL	98	REAR PAD
28	STRIKER	65	CRANK SHAFT	99	LEFT HANDLE
29	O-RING	66	CRANK SHAFT CASE	100	TAPPING SCREW ST4.2 X 20
30	PISTON	67	BEARING 6003	505	BOLT
31	O-RING	68	ORIFICE ELASTIC RETAINER	506	CHUCK RING
32	PISTON PIN	69	RETAINER RING Ø17	507	HANDLE CLIP
33	ROD	70	PIN 4 X 16	508	DEPTH GAUGE LOCK
34	NEEDLE BEARING HKHK1012	71	FIRST GEAR	509	SIDE HANDLE
35N	SMALL BEVEL GEAR	72	RETAINER RING Ø15	510	DEPTH GAUGE
36	BEARING 6002Z	73	NEEDLE BEARING HK1210	511	WASHER
37	DIRECTIONAL SLEEVE	74	SEAL WASHER	512	CHUCK RING
38	ORIFICE ELASTIC RETAINER Ø28	75	GEAR BOX		
39	BEARING 61902	76	BEARING 6001		