



RH2525V

NO.	DESCRIPTION	NO.	DESCRIPTION
1	STEEL RING 17*12	53	SPRING 7.8*1.2*11*33
2	STEEL HEAD	54	PIN A5*5*22
4	SPIN SLEEVE	55	GEAR 27:4
5	RING 21.2*31.8*6	56	PIN 8*18.7
6	SPRING 25.5*1.6*4*45	57	BUSH
7	RING 47	58	STEEL SLEEVE 22*26*9
8	OIL SEAL	59	SELF-TAPPINGS SCREW 3*6
9	RING 28*1.6	60	TWISTINC FOR HAMMER
10	BEARING61906	61	INNER COVER
11	X-RING	62	KNOB SHAFT
12	BALL7.14	63	O-RING 11*2
13	SLEEVE	64	RING 17
14	IMPACT BALL	65	BUTTOR
15	O-RING 11*2	66	SPRING 0.6*4.5*17.5
16	RUNNING PULLEY5*5	67	KNOB
17	CYLINDER	68	PLAT WASHER 4
18	PIN3*2.5*18	69	SPRING WASHER 4
19	CYLINDER HOUSE	70	SELF-TAPPINGS SCREW M4*12
20	SOKET HEAD CAPS SCREW	71	BEARING 6000
21	SPRING WASHER 5	72	ROTOR
22	PLAT WASHER 5	73	BEARING608
23	RING 30.5*40.5*1.5	74	FAN GUIDE
24	SPRING 33*3*6*60	75	SELF-TAPPINGS SCREW 3.9*55
25	GEAR 31:10	76	STATOR
26	HAMMER	77	SPRING
27	O-RING	78	SOKET HEAD CAPS SCREW
28	POSITION	79	MAIN CASE
29	PIN 6*24	80	BRUSH COVER
30	CONNECT ROD	81	BRUSH
31	BUSH	82	BRUSH HOLDER
32	BUSH	83	HANDLE
33	GEAR BOX	84	SWITCH
34	GEAR 10:31	85	CAPACITANCE
35	SPACER BUSH15*19*47	86	INDUCTANCE
36	BEARING 6002	87	SELF-TAPPING SCREW 3.9*14
37	RING14.1*19*0.5	88	CABLE BOARD
38	GEAR 39:4	89	CABLE HOLDER
39	TRIPPINC FIXED PLATE	90	CABLE
40	RING 12.5*1	91	SELF-TAPPING SCREW 5*25
41	BALL 5	92	SELF-TAPPING SCREW 3.9*25
42	TRIPPINC ACTIVE BOARD	94	SELF-TAPPING SCREW ST3.9*16
43	SPRING 14.2*9*0.5*2.7	S-1	DEPTH
44	NUT M10*0.75	S-2	HOOPE
45	BEARING627	S-3	PIN6*20
46	OIL COVER	S-4	EVELET BOLT
47	O-RING 37.5*2	S-5	BRACKET BUTTOR
48	CRANKSHAFT	S-6	SPRING W7.2*0.9*15
49	BEARING 6003	S-7	BRACKET
50	RING 28.5*34.5*1	S-8	AUXILIARY HANDLE
51	RING 35		
52	RING 17*		