



RH2585

NO.	DESCRIPTION	NO.	DESCRIPTION
1	FIXED COVER	41	"O"RING 11X3.55
2	COVER	42	FIXED SLEEVE
3	SPRING HOLDER	43	STEEL WIRE RING Ø27.5X2
4	TAPPING SCREW ST4.2X65	44	STRIKE HAMMER
5	TOWER REED	45	"O"RING 16X2.8
6	FRONT HOUSING	46	CYLINDER
7	"O"RING 38.7X1.8	47	CYLINDER PIN WASHER
8	"O"RING 5.6X2.65	48	CYLINDER PIN
9	KNOB	49	SHOCK SHAFT FIXED HOLDER
10	BRAKE BOARD	50	SEALING RING
11	TAPPING SCREW ST4.2X8	51	NEEDLE BEARING HK0608
12	SLIDE BOARD	52	PUSH PIN BEARING AXK0614
13	SLIDE BOARD HOLDER	53	SMALL GEAR
14	OIL BEARING	54	BALANCE BEARING
15	ANTIFRICTION WASHER	55	CLUTCH PIECES
16	SHOCK SHAFT	56	CLUTCH SPRING
17	PIN Ø 3X23.8	57	CLUTCH RING
18	STEEL BALL Ø7	58	TRANSFER SHAFT
19	STEEL WIRE RING Ø 34.5X2	59	BUTTERFLY-SHAPE SPRING RING
20	RING	60	BUTTERFLY-SHAPE SPRING
21	PRESS SPRING	61	BEARING 606Z
22	SLIDE GEAR	62	BEARING 608Z
23	SHAFT SLEEVE	63	ARMATURE
24	SHOCK SHAFT WASHER	64	BEARING 607Z
25	NEEDLE BEARING HK2512	65	BEARING SLEEVE
26	POSITION SCREW	66	WIND BOARD
27	REVERSE KNOB	67	STATOR
28	"O"RING 17X2.65	68	NAME PLATE
29	STEEL BALL Ø 5	69	BACK HOUSING
30	STEEL BALL SPRING	70	CARBON BRUSH ASSEMBLY
31	CLAMP KNOB	71	BRUSH HOLDER
32	PRESS BLOCK	72	SHOCK-ABSORPTION
33	ASSISTANT HANDLE	73	TAPPING SCREW ST4.2X20
34	SQUARE NUT	74	HANDLE COVER
35	DEPTH RULER	75	CAPACITOR
36	BUFFER WASHER	76	LABEL
37	POSITION BLOCK	77	SWITCH
38	HAMMER PILLAR	78	CABLE CLAMP
39	POSITION SLEEVE	79	CORD SLEEVE
40	"O"RING 18X3.55	80	CORD AND PLUG