



## TC1312P

NO.	DESCRIPTION	NO.	DESCRIPTION
1	LOCK NUT	33	BALL BEARING 6000Z
2	BLADE A&B	34	O-RING 25X2
3	GUARD PLATE	35	INTERMEDIATE COVER
4	ACTIVE GUARD	36	ARMATURE
5	ACTIVE GUARD SPRING	37	BALL BEARING 607Z
6	GUARD WASHER	38	BEARING BUSHING
7	SCREW M4X14	39	FAN GUIDE
8	FIXED GUARD	40	TAPPING SCREW ST4,2X70
9	RUBBER PIN	41	STATOR
10	SCREW M5X20	42	LUBRICATING SYSTEM
11	SPRING WASHER $\Phi 5$	43	CONNECTER
12	PLATE $\Phi 5$	44	HOUSING
13	ARBOR NUT	45	NAME PLATE
14	CIRCLIP FOR HOLE $\Phi 21$	46	BRUSH HOLDER
15	BALL BEARING 61801Z	47	CARBON BRUSH
16	INNER DRIVER	48	BRUSH CAP
17	SPRING WASHER $\Phi 4$	49	PLATE FOR INNER WIRE
18	PLATE $\Phi 4$	50	TAPING SCREW ST2,9X9,5
19	PACKER	51	ROTATION BUTTON
20	BALL BEARING 6005Z	52	SPRING FOR BUTTUN
21	GEAR A	53	SWITCH
22	BALL BEARING 6001Z	54	TAPPING SCREW ST4,2X16
23	SPINDLE	55	CORD PLATE
24	WASHER	57	POWER CORD WITH PLUG
25	GEAR B	58	CORD ARMOR
26	SCREW M4X6	59	TERMINAL
27	BEARING COVER	61	CAPACITOR
28	BALL BEARING 608RS	62	AUXILIARY HANDLE
29	GEAR CASE	63	HEX NUT M8X10
30	TAPPING SCREW ST4,2X32	64	BOX WRENCH
31	CAP	65	AUXILIARY HANDLE SUPPORT
32	PINION	888	HANDLE ASSEMBLE

ST20120420