



TC9822U

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	PUMP	33	SCREW FOR FLANGE	67	KNOB
2	RUBBER COVER	34	NUT	68	POSITION PIECE
3	CABLE GLOVE	35	SLIDING PLATE	70	CROSS-HEAD SCREW
4	SWITCH	36	CROSSING-CUTTING FENCE	71	ADJUSTABLE HANDLE
5	SWITCH BOX	37	PLATE FOR CROSSING-CUTTING FENCE	72	LEFT ANGLE BOARD
6	TAPPING SCREW	38	KNOB	73	HEXAGON POLE
7	CAPACITOR CLIP	39	PLUG	74	LEFT SUPPORTING BOARD
8	CAPACITOR	40	PLASTIC CHAIN	75	TABLE
9	TAPPING SCREW	42	GUIDE	76	CHAIN
10	SWITCH BOX COVER	43	RIGHT ANGLE BOARD	77	CROSS-HEAD SCREW
11	SWITCH BOX COVER WASHER	44	SCREW FOR FLANGE	78	SPRING WASHER
12	TAPPING SCREW	45	SCREW	80	NUT
13	PRESSING-CORD BOARD	46	FLAT WASHER	81	SPRING WASHER
14	CROSS-HEAD SCREW	47	SUNK SCREW	82	M6 PAPILOACEOUS SCREW NUT
15	CABLE GLAND	48	RIGHT SUPPORTING BOARD	83	SPLINT FOR PROTECTIVE-WATER BOARD
16	HANDLE B	49	NUT	84	PROTECTIVE-WATER BOARD
17	SUNK SCREW	51	RUBBER FEET	85	SQUARE NECK SCREW
18	MOTOR FIXING FRAME	52	FLAT WASHER	86	RUBBER NAIL
19	INNER GUARD	53	ROUND-HEAD SCREW	87	NUT
20	FLAT WASHER	54	HEXAGONAL SCREW	88	PREJUDICIAL ARBOR
21	CROSS-HEAD SCREW	55	FLAT WASHER	91	BEARING
22	BLOCKING WATER RING	56	SPRING WASHER	93	MOTOR
23	INNER FLANGE	57	NUT	100	CHAIN SUPPORT PLATE
24	BLADE	58	SUPPORT PLATE	101	INDICATOR
25	OUTER FLANGE	59	KNOB NUT	102	FLAT WASHER
26	NUT	60	WATER TROUGH	103	SPRING WASHER
27	OUTER GUARD	61	FLAT WASHER	104	NUT
28	FLAT WASHER	62	SCREW		
29	SPRING WASHER	63	WATER TANK		
30	LOCKNUT	64	KNOB		
31	KNOB NUT	65	RUBBER FEET		
32	RIP FENCE	66	SUPPORT LEG		

ST20110214