



# WM1921

LT01

No.	Name (specification)	No.	Name (specification)
1	back bench	27	locking bar
2	chamfering guide	28	left slider
3	back lip plate (2)	29	spring
4	planing tool (3)	30	tool adjust spring
5	tool presser (3)	31	limit pin
6	arbor	32	arbor hood
7	flat spacer (4)	33	left bearing base
8	right bearing base	34	bearing cover
9	distance spacer	35	spacer
10	bearing cover	36	hood base
11	pulley	37	screw arbor
12	press disk	38	tool cover
13	nut (2)	39	down supporter
14	shield ring (2)	40	up supporter
15	guide	41	supporter base
16	sliding base	B1	hard carbide saw blade 250x3.2x30
17	nut (2)	B2	V-belt A800 (2)
18	locking fastening	B3	single-row radial ball bearing 204 (2)
19	square guide	B4	adjustable locking knob BM8x63x20
20	right slider	B5	knob case M8x25
21	front bench	B6	open-ended pin 2.5x20
22	ruler	B7	knob case M6x20
23	guide track	B8	drill bit Ø10x133
24	knob	B9	drill chuck Js 13/2
25	round guide	B10	cross knob 8x40 α
26	back stopper		

RU050901-1