


WM1922 Part List LT01

WM1922 LT01



NO	DESCRIPTION	NO	DESCRIPTION
1	RIGHT TRACKWAY	43	MOVABLE PLATE
2	SUPPORTER	44	CHIP BREAKER
3	FRONT HOOD	45	PIN
4	CASE (4)	46	BRIDGE GUARD
5	SCALE BASE	47	SUPPORTING BASE
6	SCALE	48	UP SUPPORTER
7	SLIDING BASE	49	DOWN SUPPORTER
8	SQUARE NUT	50	PAD PLATE
9	SUPPORT PLATE	51	HOOD BASE
10	FRONT TABLE	52	SCREW ARBOR
11	NUT (2)	53	BACK HOOD
12	GUIDE	54	BACK TABLE
13	PAD PLATE	55	BACK LIP (2)
14	PRESSER	56	LIMITING PLATE
15	HOOD	57	LOCATING PIN
16	HANDLE	58	BACK STOPPER (21)
17	ELEVATING SPANNER	59	BOLT (4)
18	LEFT TRACKWAY	60	GROOVED ROLLER
19	BLADE (3)	61	BACK STOPPER SHAFT
20	BEARING BLOCK (4)	62	PRESS ROLLER
21	PLANER SPINDLE	63	TOOL PRESSER (3)
22	LEFT BEARING BASE	64	SUPPORT BAR
23	DRILLING HOOD	65	RIGHT BEARING BASE
24	CONNECT CASE	66	ADJUSTABLE PAD
25	SPINDLE HOOD	67	DISTANCE SLEEVE
26	DRILL CHUCK	68	PRESSER
27	TOOL PRESSER (2)	69	BEARING COVER
28	FLAT MILLING UTTER (2)	70	TOOL SPINDLE PULLEY
29	SPRING (2)	71	SPACER (2)
30	WORKPIECE PRESSER	72	BIG SPROCKET (2)
31	MILLING CUTTER HOOD	73	PRESS SPACER (2)
32	NUT	74	SAW BASE
33	DISTANCE CASE	75	ADJUSTABLE PAD
34	PRESSER	76	NUT (2)
36	LOCKING BAR	B1	KNOB BM8X63X20
37	HANDLE	B2	KNOB COVER BM10X50
38	DISTANCE SLEEVE	B3	MILLING BLADE \varnothing 10X100
39	BEARING COVER	B4	BEARING 204 (2)
40	TOOL PAN	B5	HANDLE 8X40
41	FIXING BASE	B6	BIKE CHAIN 12.7-68 JOINT
42	SPRING (2)	B7	CARBID SAW BLADE 50X3X25.4