



WP9742VS

NO.	DESCRIPTION	NO.	DESCRIPTION
1	DISCHARGE SCREW	18	FAN COVER
2	PUMP BODY FRONT COVER	19	MOTOR END COVER
3	SCREW	20	SPRING WASHER(OPTIONAL)
4	MECHANICAL SEAL 1	21	CABLE & PLUG
5	MECHANICAL SEAL 2	22	SCREW
6	SCREW	23	CAPACITOR
7	RUBBER RING	24	CAPACITOR COVER
8	MOTOR FRONT COVER	25	PRESSURE TANK
9	BEARING 6201	26	PRESSURE SWITCH
10	PIN	27	PLUG SCREW
11	ROTOR	28	PUMP BODY
12	STATOR	29	INLET CHECK VALVE
13	BASE	30	INLET PORT
14	STATOR HOUSING	31	CIRCLIP
15	BEARING 6201	32	IMPELLER
16	MOTOR FIX SCREW		
17	FAN		

ST20101025