



# WP9714WI WP9714WT

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	38	GUIDE FLOWING PIECE
2	MOTOR HOUSING	39	"O" RING
3	FAN	40	PUMP HEAD
4	REAR COVER	41	VALVE COVER
5	WAVEFORM WASHER	42	MIDDLE SEALING BUSH
6	BOLT	43	"O" RING
7	ALUMINIUM HOUSING	44	DUSTPROOF COVER
8	BEARING 6201	45	SCREW
9	ROTOR	46	STATOR
10	BEARING 6202	47	CIRCLIP
11	CORD SLEEVE	48	VALVE COVER
12	CAPACITOR	49	SMALL SEALING BUSH
13	TAPPING SCREW	50	"O" RING
14	CORD CLAMP	901	MECHANISM PRESSURE SWITCH
15	CORD SLEEVE(NR)	902	FIVE DIRECTION CONNECTOR
16	CORD SLEEVE	903	SOFT TUBE
17	CORD & PLUG	904	SEALING WASHER
18	WATERPROOF COVER	905	PRESSURE POT
19	TAPPING SCREW	905-1	NUT
20	"O" RING	905-2	WASHER
21	SIDE COVER	905-3	PLASTIC SUPPORT
22	SEALING WASHER	905-4	PRESSURE POT BODY
23	WATERPROOF SWITCH	905-5	WATER VESICLE
24	TAPPING SCREW	905-6	FLANGE
25	HANDLE	905-7	BOLT
27	HEX NUT	905-8	PLASTIC BOTTOM
28	BASE	905-9	VALVE COVER
29	TAPPING SCREW	905-10	VALVE
30	FORE COVER	905-11	WASHER
31	SWING RING	905-12	PRESS PLATE
32	"O" RING	905-13	NUT
33	SEALING PLATE	906	BOLT
34	MECHANISM SEALING	907	NUT
35	IMPELLER	908	PRESSURE METER
36	GUIDE FLOWING PLATE	909	CORD
37	"O" RING	101	STATOR ASSEMBLY(7+46)

ST20120412-01