


## S(L) (CVM7100 (O)

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SPINDLE	16	WIND GUARD
2	KEY	17	SCREW
3	BEARING 6200RS	18	STATOR
4	SCREW	19	HOUSING
5	GEAR BOX	20	SWITCH
6	GEAR	23	CORD CLAMP
7	CIRCLIP	24	SCREW
8	BRUSH HOLDER CAP	25	CORD SLEEVE
9	MIDDLE COVER	26	CORD
10	BEARING 6200RS	27	CIRCLIP
11	ROTOR	28	SCREW
12	CARBON BRUSH	29	SIDE HANDLE
13	CARBON BRUSH HOLDER	990	VIBRATION SPEAR
14	BEARING 608Z	888	HANDLE ASSEMBLE
15	WASHER		

ST-UKW231013

## Stumaxo

Stumaxo



## Vibrator for CVM7100

NO.	DESCRIPTION
1	CAP HEAD
2	O-RING
3	CASE
4	ROTARY SHAFT
5	COUNTER OIL SEAL
6	OILSEAL
7	BEARING
8	SHAFT JOINT
9	FLEXILE SHAFT
10	SHAFT JOINT
11	HEX SHAFT JOINT
12	FLEXILE HOSE
/13	LOCKING NUT

ST-UKW231013

Stumaxo